



Features

- 32 Tones, adjustable volume from 90.1 to 92.4 dB(A)
- Bi-directional wireless communication
- Automatic wireless channel hopping
- Easy and cost-effective additions toexisting wired systems
- Compliant with AS4428.9
- SAI Global Approved

Description

The RSM-BS-AS is base sounder unit providing a fixing base for any of the FIREwave range of sensors and an audio alarm.

The units parameters are programmed via the Translator Module (RSM-WTM-AS) and a PC link. The Translator Module then automatically manages wireless radiated power depending on the device communication quality. The unit is controllable from the Control Panel via the Translator Module and offers the same level of flexibility as a standard addressable loop sounder

The base sounder features 32 tone settings as standard with two volume settings allowing adjustment up to 92 dB(A) at 1 metre.

The unit also comes with a pre-moulded base which will accommodate any type of FIREwave wireless detector, or can be removed to accomodate a locking cover plate.

00

RSM-BS-AS	
100 m (open space)	
916 MHz	
Frequency Shift Keying	
6	
From 7 seconds to 1 minute	
1 x Primary Cell	1 x Secondary Cell
(CR123A)	(CR123A)
1.2 Ahr	1.2 Ahr
3 years	3 months
-10 °C to +55 °C	
3 mW (typical)	
88 to 92 dB(A) at 1 metre	
H51 x W115 (diameter)	
	100 m (open space)916 MHzFrequency Shift Keying6From 7 seconds to 1 minu1 x Primary Cell(CR123A)1.2 Ahr3 years-10 °C to +55 °C3 mW (typical)88 to 92 dB(A) at 1 metre

*dependent on time period between wireless signal transmissions

Hochiki Europe (UK) Ltd. reserves the right to alter the specification of its products from time to time without notice. Although every effort has been made to ensure the accuracy of the information contained in this document it is not warranted or represented by Hochiki Europe (UK) Ltd. to be a complete and up-to-date description.